```
* imx219.c - imx219 sensor driver
 * Copyright (c) 2015, NVIDIA CORPORATION, All Rights Reserved.
 * This program is free software; you can redistribute it and/or modify it
 * under the terms and conditions of the GNU General Public License,
 * version 2, as published by the Free Software Foundation.
 * This program is distributed in the hope it will be useful, but WITHOUT
 * ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or
 * FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for
 * more details.
 * You should have received a copy of the GNU General Public License
 * along with this program. If not, see <http://www.gnu.org/licenses/>.
#include <media/camera common.h>
#ifndef __IMX219_I2C_TABLES
#define IMX219 I2C TABLES
#define IMX219 TABLE WAIT MS 0
#define IMX219 TABLE END 1
#define IMX219 MAX RETRIES 3
#define IMX219 WAIT MS
#define imx219 reg struct reg 8
static imx219 reg imx219 start[] = {
  { 0x0100, 0x01 }, /* mode select streaming on */
  { IMX219 TABLE END, 0 \times 00 }
};
static imx219 reg imx219 stop[] = {
  { 0x0100, 0x00 }, /* mode select streaming off */
  { IMX219 TABLE END, 0\times00 }
};
/* 0.912 GHz */
static imx219 reg mode 1920x1080[] = {
  {IMX219 TABLE WAIT MS, 10},
  /* analogue gain setting */
  \{0 \times 0157, 0 \times 00\},\
  /* 0x0158, 0x159 Digital gain */
  /* Course Time */
  \{0 \times 015A, 0 \times 04\},\
  \{0x015B, 0x22\},\
  /* Frame Length: 1766 */
  \{0 \times 0160, 0 \times 06\},\
  \{0 \times 0161, 0 \times E6\},\
  /* line length: 3448 */
  \{0 \times 0162, 0 \times 0D\},\
  \{0x0163, 0x78\},\
  /* Image Width: 2599 - 680 = 1920 - 1 */
  /* crop_rect.left: 680 Offset */
  \{0x0164, 0x02\},\
  \{0x0165, 0xA8\},\
```

```
/* crop rect.width - 1: 2599 */
  \{0 \times 0166, 0 \times 0A\},\
  \{0 \times 0167, 0 \times 27\}
  /* Image Height: 1771 - 692 = 1080 - 1 */
  /* crop_rect.top: 692 */
  \{0x0168, 0x02\},\
  {0x0169, 0xB4},
  /* crop_rect.height - 1: 1771 */
  \{0 \times 016A, 0 \times 06\},\
  {0x016B, 0xEB},
  /* crop rect.width: 1920 */
  \{0 \times 016C, 0 \times 07\},\
  {0x016D, 0x80},
  /* crop rect.height: 1080 */
  \{0 \times 016E, 0 \times 04\},\
  {0x016F, 0x38},
  /* X odd increment: 1 */
  \{0 \times 0170, 0 \times 01\},\
  /* Y odd increment: 1 */
  \{0 \times 0171, 0 \times 01\},\
  /* Binning Mode Horizontal: 0 */
  \{0 \times 0174, 0 \times 00\},\
  /* Binning Mode Horizontal: 1 */
  \{0 \times 0175, 0 \times 00\}
};
static imx219_reg mode_1280x720[] = {
  {IMX219_TABLE_WAIT_MS, 10},
  /* Course Time */
  \{0 \times 015A, 0 \times 04\},\
  \{0x015B, 0x22\},\
  /* Frame Length: 1766 */
  \{0 \times 0160, 0 \times 06\},\
  {0x0161, 0xE3},
  /* Line Length: 3448 */
  \{0 \times 0162, 0 \times 0D\},\
  \{0x0163, 0x78\},\
  /* Image Width: 2919 - 360 = 2560 - 1 (2 X 1280) */
  /* crop_rect.left: 360 */
  \{0 \times 0164, 0 \times 01\},\
  \{0x0165, 0x68\},\
  /* crop_rect.width: 2919 */
  \{0x0166, 0x0B\},\
  \{0 \times 0167, 0 \times 67\},\
  /* Image Height: 1953 - 512 = 1442 - 1 (2 X 720) */
  /* crop_rect.top: 512 */
  \{0x0168, 0x02\},\
  \{0 \times 0169, 0 \times 00\},\
```

/* X odd increment */

```
\{0 \times 0170, 0 \times 01\},\
  /* Y odd increment */
  \{0\times0171, 0\times01\},\
  /* Binning Mode: X (2) */
  \{0\times0174, 0\times01\},\
  /* Binning Mode: Y (2) */
  \{0 \times 0175, 0 \times 01\}
};
static imx219 reg mode table common[] = {
  /* software reset */
  \{0 \times 0103, 0 \times 01\},\
  /* Access Code to registers over 0x3000 */
  \{0x30EB, 0x05\},\
  \{0x30EB, 0x0C\},\
  {0x300A, 0xFF},
  \{0x300B, 0xFF\},\
  \{0x30EB, 0x05\},\
  \{0x30EB, 0x09\},
  /* number of csi lanes = 2 (1 + 1) */
  \{0 \times 0114, 0 \times 01\},\
  /* CSI data format */
  \{0 \times 018C, 0 \times 0A\},\
  \{0 \times 018D, 0 \times 0A\},\
  /* dphy control */
  \{0 \times 0128, 0 \times 00\},\
  /* external clock frequency = 24MHz ?? */
  \{0 \times 012A, 0 \times 18\},\
  \{0 \times 012B, 0 \times 00\}
  /* analogue gain setting */
  \{0 \times 0157, 0 \times 00\},\
  /* 0x0158, 0x159 Digital gain */
  //Clock Settings
  /* VTPXCK DIV */
  \{0x0301, 0x05\},\
  /* VTSYS_DIV = 1 (Divide by 1 I think)*/
  \{0x0303, 0x01\},\
  /* PREPLLCK_VT_DIV */
  \{0x0304, 0x03\},\
  /* PREPLLCK OP DIV */
  \{0x0305, 0x03\},\
  /* PLL_VT_MPY = 57*/
  \{0x0306, 0x00\},\
  \{0x0307, 0x39\},\
  /* OPPXCK_DIV */
  \{0x0309, 0x0A\},\
  /* OPSYSCK DIV = 1 (Divide by 1 I think) */
  \{0x030B, 0x01\},\
  /* PLL_OP_MPY = 114*/
  \{0x030C, 0x00\},\
  \{0x030D, 0x72\},\
  /* CIS tunning */
  \{0x455E, 0x00\},
  \{0 \times 471E, 0 \times 4B\},
  \{0x4767, 0x0F\},\
  \{0x4750, 0x14\},\
```

```
\{0x4540, 0x00\},\
  \{0x47B4, 0x14\},
  \{0x4713, 0x30\},\
  \{0x478B, 0x10\},
  {0x478F, 0x10},
  \{0x4793, 0x10\},\
  \{0x4797, 0x0E\},\
  {0x479B, 0x0E}
};
enum {
  IMX219 MODE 1920X1080,
  IMX219 MODE 1280X720,
  IMX219 MODE 640X480,
  IMX219 MODE COMMON,
  IMX219 MODE START STREAM,
  IMX219 MODE STOP STREAM,
  IMX219 MODE TEST PATTERN,
};
static imx219 reg *mode table[] = {
  [IMX219 MODE 1920X1080]
                             = mode 1920x1080,
  [IMX219 MODE 1280X720]
                               = mode 1280x720,
  [IMX219 MODE 640X480]
                               = mode 640x480,
  [IMX219 MODE COMMON]
                               = mode table common,
  [IMX219 MODE START STREAM] = imx219 start,
  [IMX219 MODE STOP STREAM]
                               = imx219 stop,
};
static const int imx219 30fps[] = {
  10,
  1,
};
static const int imx219 60fps[] = {
  60,
  30,
  10,
  1,
};
camera common frmfmt: {struct v4l2 frmsize discrete size}, {const int *framerates}, {num framerates},
{hdr en}, {int mode}
static const struct camera common frmfmt imx219 frmfmt[] = {
                                 Num Framerates, HDR Enable,
// Frame Size,
                Framerates??,
                                                                  Mode
                                                                                             },
                                                                  IMX219_MODE_1920X1080
  {{1920,1080},
                  imx219 30fps,
                                   3,
                                                    Θ,
  {{1280,720},
                  imx219_60fps,
                                   4,
                                                    0,
                                                                  IMX219_MODE_1280X720
                                                                                             },
                                   4,
  {{640,480},
                                                                                             },
                  imx219 60fps,
                                                    Θ,
                                                                  IMX219 MODE 640X480
};
```

#endif /* __IMX219_I2C_TABLES_ */